



CYLINDER, CYLINDER HEAD 汽缸、汽缸頭




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	11111-STG-00	CYLINDER COMP	1	汽缸
2	11121-STG-01	HEAD COMP, CYLINDER	1	汽缸頭
3	11127-CHP-00	NUT, CYLINDER HEAD	4	汽缸頭螺帽
4	11141-ROA-00	COVER, CYLINDER HEAD	1	汽缸頭蓋
5	11151-CHI-00	GASKET, CYLINDER	1	汽缸墊片
6	11181-STG-00	GASKET, CYLINDER HEAD	1	汽缸頭墊片
7	11191-CHP-00	GASKET, HEAD COVER	1	汽缸頭蓋墊圈
8	62210-CHP-00	PLUG, SPARK (DR8EA NGK)	1	火星塞
9	94410-10020	PIN, DOWEL 10*20	3	定位銷
10	94717-07037-B	BOLT, STUD 7*37	2	雙頭螺栓
11	96210-08079-B	BOLT, HEXAGON 8*79	1	六角螺栓
12	96414-06012-B	BOLT, FLANGE 6*12	1	凸緣螺栓
13	96414-06022-B	BOLT, FLANGE 6*22	2	凸緣螺栓
14	96414-06028-B	BOLT, FLANGE 6*28	3	凸緣螺栓
15	97201-122223-B	WASHER, PLANE 12.6*22*2.3	2	平面墊圈
16	97230-061212	WASHER, COPPER 6.4*12*1.2	1	銅墊圈
17	97230-081823	WASHER, COPPER 8.6*18*2.3	1	銅墊圈

CRANKSHAFT, PISTON 曲軸.活塞



NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	11400-CHP-00	CRANKSHAFT COMP	曲軸總成	1	
2	11631-STG-00	PISTON	活塞	1	
3	11636-STG-00	RING SET, PISTON	活塞環組	1	
4	14311-CHP-00	GEAR, TIMING DRIVE (22T)	正時齒輪	1	
5	15120-CHP-00	PLUG ASS'Y, BEARING PUSH	軸承推栓總成	1	
6	93110-34507	OIL SEAL 34*50*7	油封	1	
7	93210-25130	O-RING 2.5*13.0	護油圈	1	
8	93320-286818V	BALL BEARING 6328V4	滾珠軸承	1	
9	93320-286818JU	BALL BEARING 6328JR2LUA	滾珠軸承	1	
10	93510-091553	PIN, PISTON	活塞銷	1	
11	94420-04025	KEY, WOODRUFF 25*14*4	半圓鍵	1	
12	96414-06025-B	BOLT, FLANGE 6*25	凸緣螺栓	1	
13	97050-10017	CIRCLIP, PISTON PIN 15MM	活塞銷止動環	2	
14	97201-061415-B	WASHER, PLANE 6.2*14*1.5	平面墊圈	1	

OIL PUMP 機油泵




NO.	PARTS NO.	PARTS NAME	QTY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	13100-CHI-00	PUMP ASS'Y,OIL	1	機油泵總成
2	13111-CHI-00	BODY,OIL PUMP	1	機油泵本體
3	13112-CHP-00	COVER,OIL PUMP GEAR	1	機油泵齒輪蓋
4	13116-CHP-00	PLATE,OIL PUMP	1	機油泵平板
5	13121-CHP-00	SHAFT,OIL PUMP	1	機油泵齒輪軸
6	13124-CHI-00	GEAR,OIL PUMP	1	機油泵齒輪
7	13141-CHI-00	ROTOR,OIL PUMP INNER	1	機油泵內轉子
8	13142-CHI-00	ROTOR,OIL PUMP OUTER	1	機油泵外轉子
9	13151-CHP-00	GASKET,OIL PUMP	1	機油泵墊片
10	13301-CHP-00	OIL FILTER ROTOR ASS'Y	1	濾油網轉子總成
11	13310-CHP-00	ROTOR,OIL FILTER	1	濾油網轉子
12	13311-CHP-00	CAP,OIL FILTER ROTOR	1	濾油網轉子蓋
13	13316-CHP-00	WASHER,OIL FILTER ROTOR	1	濾油網轉子蓋墊片
14	13321-CHP-00	THROUGH OIL	1	通油器
15	13324-CHP-00	SPRING,OIL THROUGH	1	通油器彈簧
16	25641-CHP-00	GEAR,PRIMARY DRIVE (18T)	1	第一驅動齒輪
17	90230-12008	COTTER PIN 1.2*8	1	開尾銷
18	93210-24094	O-RING 2.4*9.4	2	護油圈
19	94712-04012-K	SCREW,FLAT HEAD 4*12	2	十字孔埋頭螺絲
20	94712-05012-C	SCREW,FLAT HEAD 5*12	3	十字孔埋頭螺絲
21	94712-06030-B	SCREW,FLAT HEAD 6*30	2	十字孔埋頭螺絲
22	95601-162810	NUT,RING 16MM	1	環形螺帽

2004.05.07

13100-CHI-00A

OIL PUMP 機油泵




NO.	PARTS NO.	PARTS NAME	QTY	NOTE
項目	零件號碼	零件名稱	用量	備註
23	96210-05020-C	BOLT,HEXAGON 5*20	2	六角螺栓
24	97310-162720	WASHER,CONICAL SPRING 16.4*26.8*	1	錐形彈簧墊圈

2004.05.07


13100-CHI-00A

CARBURETOR 化油器



NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	13201-STG-00	CARBURETOR ASS'Y	1	化油器總成
2	13240-STG-00	JET, MAIN #108	1	主噴口
3	13242-STG-00	JET, SLOW #40	1	引導噴口
4	13276-RAM-00	HOLDER, CHOKE CABLE	1	阻風導線固定座
5	13278-RAM-00	SPRING, TORSION	1	阻風閥扭轉彈簧
6	13620-ROA-00	INSULATOR, CARB COMP	1	汽化器絕緣管
7	13626-ROA-00	INSULATOR ASS'Y, CARB COMP	1	汽化器絕緣管組
8	93210-30335	O-RING 3*33.5	1	護油圈
9	94717-06028-B	BOLT, STUD 6*28	2	雙頭螺栓
10	95401-061006-B	NUT, FLANGE 6MM	2	凸緣螺帽
11	96414-06020-B	BOLT, FLANGE 6*20	2	凸緣螺栓

VALVE 閥門




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	14111-CHP-00	FOLLOWER,CAM	2	
2	14120-CHI-00	SHAFT COMP,CAM FOLLOWER	1	
3	14121-CHI-00	SHAFT,CAM FOLLOWER	1	
4	14130-CHI-00	SHAFT COMP,CAM GEAR	1	
5	14131-CHI-00	SHAFT,CAM GEAR	1	
6	14133-CHP-00	SPRING,CAM SHAFT	1	
7	14134-CHP-00	PLATE,SPG STOPPER	1	
8	14136-CHP-00	CAMSHAFT COMP	1	
9	14431-CHP-00	HOLDER COMP,ROCKER ARM	1	
10	14436-CHP-00	SCREW,TAPPET ADJUSTING	2	
11	14437-CHP-00	NUT,TAPPET ADJUSTING	2	
12	14501-CHP-00	ROD PUSH	2	
13	14560-CHP-00	GUIDE PUSH ROD	1	
14	14711-CHI-00	VALVE,IN	1	
15	14721-CHI-00	VALVE,EX	1	
16	14731-CHP-00	SEAL,VALVE STEM	2	
17	14751-CHP-00	SPRING,VALVE OUTER	2	
18	14761-CHP-00	SPRING,VALVE INNER	2	
19	14771-CHP-00	RETAINER,VALVE SPRING	2	
20	14781-CHP-00	COTTER,VALVE	4	
21	93210-25170	O-RING 2.5*17	1	
22	93210-25200	O-RING 2.5*20	1	

2004.05.07

14111-CHI-00A

VALVE 閥門




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
23	96210-08028-B	BOLT,HEXAGON 8*28	3	
24	96411-06012-B	BOLT,FLANGE 6*12	1	
25	97201-121805	SEAT,VALVE SPRING INNER 12.7*17.6*0.1	2	
26	97201-142410	WASHER,THRUST 14.3*23.8*1	1	
27	97201-182610	SEAT,VALVE SPRING OUTER 18.9*26.2*1	2	
28	97230-081823	WASHER,COPPER 8.6*18*2.3	3	
29	97311-122102	WASHER,WAVE 12.3*21*0.2	1	

2004.05.07


14111-CHI-00A

CRANKCASE 曲軸箱




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	15111-CHI-00	CRANKCASE, LEFT	1	左曲軸箱
2	15211-CHI-00	CRANKCASE, RIGHT	1	右曲軸箱
3	15251-CHI-00	GASKET, CRANKCASE	1	曲軸箱墊片
4	15276-CHP-00	HOSE	1	通氣管
5	15531-CHP-00	CAP ASS'Y, OIL FILTER SCREEN	1	濾油網螺帽蓋組
6	15533-CHP-00	CAP, OIL FILTER SCREEN	1	濾油網螺帽蓋
7	15536-CHP-00	SCREEN, OIL FILTER	1	濾油網
8	15538-CHP-00	SPRING, OIL FILTER SCREEN	1	濾油網彈簧
9	25793-CHP-00	HOLDER, CLUTCH WIRE	1	離合器導線固定座
10	90210-10015	CLIP 1.0*14.7	1	管夾
11	93210-30350	O-RING 3.0*35	1	護油圈
12	94410-10014	PIN, DOWEL 10*14	4	定位銷
13	96610-06055-B	BOLT 6*55	1	六角十字穴螺栓
14	94717-08122-C	BOLT, STUD 8*122	2	雙頭螺栓
15	94717-08130-C	BOLT, STUD 8*130	2	雙頭螺栓
16	96411-06050-B	BOLT, FLANGE 6*50	9	凸緣螺栓
17	96411-06095-B	BOLT, FLANGE 6*95	1	凸緣螺栓
18	96414-12015-B	BOLT, FLANGE 12*15	1	凸緣螺栓
19	97231-122020	WASHER, ALUMINUM 12.3*20*2	1	鋁墊圈

LEFT CRANKCASE COVER 左曲軸箱蓋




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	12655-ROA-00	CAP, A.C.G	1	A.C.G 蓋
2	15411-CHP-00	COVER, L CRANKCASE	1	左曲軸箱蓋
3	15416-CHP-00	COVER, REDUCTION GEAR	1	減速齒輪蓋
4	15417-CHP-00	CAP, L CRANKCASE COVER	1	左曲軸箱蓋飾蓋
5	15481-CHP-00	GASKET, L CRANKCASE COVER	1	左曲軸箱蓋墊片
6	15541-CHP-00	CLAMPER, WIRE HARNESS	1	配線固定板
7	35500-CHP-00	GENERATOR ASS'Y	1	發電機總成
8	35550-CHP-00	FLYWHEEL COMP	1	轉子總成
9	35560-CHP-00	STATOR COMP	1	發電機座總成
10	93210-24274	O-RING 2.4*27.4	1	護油圈
11	93210-25138	O-RING 2.5*13.8	1	護油圈
12	93210-30630	O-RING 3.0*63	1	護油圈
13	94410-10014	PIN, DOWEL 10*14	2	定位銷
14	96210-05025-B	BOLT, HEXAGON 5*25	3	六角螺栓
15	96310-05016-B	SCREW, PAN HEAD 5*16	2	十字孔頭螺絲
16	96411-06012-B	BOLT, FLANGE 6*12	1	凸緣螺栓
17	96411-06020-B	BOLT, FLANGE 6*20	3	凸緣螺栓
18	96411-06025-B	BOLT, FLANGE 6*25	1	凸緣螺栓
19	96411-06040-B	BOLT, FLANGE 6*40	5	凸緣螺栓
20	96411-06050-B	BOLT, FLANGE 6*50	2	凸緣螺栓
21	96414-10036-B	BOLT, FLANGE 10*36	1	凸緣螺栓

RIGHT CRANKCASE COVER 右曲軸箱蓋



NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	15221-CHP-00	GASKET, R CRANKCASE COVER	右曲軸箱蓋墊片	1	
2	15511-RAM-00	COVER, R CRANKCASE COMP	右曲軸箱蓋	1	
3	15561-CHP-00	GAUGE ASS'Y, OIL LEVEL	量油尺組	1	
4	15563-CHP-00	GAUGE, OIL LEVEL	量油尺	1	
5	25723-CHP-00	LEVER, CLUTCH	離合器拉桿	1	
6	25725-CHP-00	LEVER COMP, CLUTCH	離合器拉桿組	1	
7	25732-CHP-00	CAM, CLUTCH LIFTER	離合舉動凸輪	1	
8	25753-CHP-00	SPRING, CLUTCH LEVER	離合器拉桿彈簧	1	
9	90240-18016-B	COTTER PIN 1.8*16	開口銷	1	
10	93210-19068	O-RING 1.9*6.8	護油圈	1	
11	93210-30180	O-RING 3*18	護油圈	1	
12	94410-08014	PIN, DOWEL 8*14	定位銷	2	
13	96411-06040-B	BOLT, FLANGE 6*40	凸緣螺栓	10	
14	96411-06050-B	BOLT, FLANGE 6*50	凸緣螺栓	1	

TRANSMISSION.STARTER 傳動系統,起動系統




NO.	PARTS NO.	PARTS NAME	QTY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	25711-RAM-00	SPROCKET DRIVE 12T	1	驅動鏈輪
2	25716-CHP-00	PLATE, FIXING	1	驅動鏈輪固定板
3	25757-RAM-00	GEAR, IDLE STARTER	1	起動惰齒輪軸襯
4	26100-RAM-01	MAIN SHAFT ASS'Y	1	主軸總成
5	26110-RAM-00	GEAR, STARTER	1	起動桿齒輪
6	26111-CHP-00	MAIN SHAFT, TRANSMISSION 13T	1	傳動主軸
7	26118-CHP-00	WASHER, SPLINE 2.3*26*1.6	3	齒輪墊圈
8	26120-CHP-00	GEAR, MAIN SHAFT SECOND 17T	1	主軸二速齒輪
9	26130-RAM-00	GEAR, MAIN SHAFT THIRD 20T	1	主軸三速齒輪
10	26140-CHP-00	GEAR, MAIN SHAFT FOURTH 23T	1	主軸四速齒輪
11	26150-CHP-00	GEAR, MAIN SHAFT FIFTH 25T	1	主軸五速齒輪
12	26400-RAM-01	COUNTER SHAFT ASS'Y	1	副軸總成
13	26410-CHP-00	GEAR, COUNTER SHAFT LOW 36T	1	副軸低速齒輪
14	26411-CHP-00	COUNTER SHAFT, TRANSMISSION	1	傳動副軸
15	26420-CHP-00	GEAR, COUNTER SHAFT SECOND 32	1	副軸二速齒輪
16	26430-RAM-00	GEAR, COUNTER SHAFT THIRD 28T	1	副軸三速齒輪
17	26440-CHP-00	GEAR, COUNTER SHAFT FOURTH 26	1	副軸四速齒輪
18	26450-CHP-00	GEAR, COUNTER SHAFT FIFTH 24T	1	副軸五速齒輪
19	93110-20347	OIL SEAL 20*34*7	1	油封
20	93310-1521120	BEARING, NEEDLE HK1512	1	滾針軸承
21	93320-153511Z	BEARING, RADIAL BALL 6202Z	1	滾珠軸承
22	93320-2047143	BEARING, RADIAL BALL 6204C3	1	滾珠軸承

2004.05.07

26100-RAM-01A

TRANSMISSION.STARTER 傳動系統,起動系統




NO.	PARTS NO.	PARTS NAME	QTY	NOTE
項目	零件號碼	零件名稱	用量	備註
23	93320-305513M	BEARING, RADIAL BALL 6006CM	1	滾珠軸承
24	96210-06010-B	BOLT, HEXAGON 6*10	2	六角螺栓
25	97014-20012	CIRCLIP 20MM	3	C形扣環
26	97201-152510	WASHER, THRUST 15.4*24.8*1	1	平面墊圈
27	97201-153010	WASHER, THRUST 15.2*30*1	1	平面墊圈
28	97201-172405	WASHER, THRUST 16.8*24*0.5	2	平面墊圈
29	97201-202705	WASHER, THRUST 20.4*26.8*0.5	1	平面墊圈
30	97201-202710	WASHER, THRUST 20.4*26.8*1	1	平面墊圈


2004.05.07

26100-RAM-01A

STARTING MOTOR 起動馬達




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	23524-CHP-00	GEAR COMP, STARTING CLUTCH	1	起動輪
2	23570-CHP-00	STARTING CLUTCH ASS'Y	1	起動離合器總成
3	23574-CHP-00	OUTER COMP, STARTING CLUTCH	1	起動離合器座
4	23576-CHP-00	ROLLER 10*12	3	起動離合器滾珠
5	23578-CHP-00	CAP, STARTING CLUTCH ROLLER SPRING	3	起動離合器彈簧套
6	23612-CHP-00	SHAFT, STARTER GEAR	1	起動齒輪軸
7	23632-CHP-00	PLATE, SET GEAR	1	齒輪固定板
8	23660-CHP-00	GEAR, REDUCTION	1	減速齒輪
9	23663-CHP-00	SHAFT, REDUCTION GEAR 10*45	1	減速齒輪軸
10	35800-CHP-00	MOTOR ASS'Y, STARTER	1	起動馬達總成
11	35831-CHP-00	CABLE, STARTER MOTOR	1	起動馬達配線
12	93210-31244	O-RING 3.1*24.4	1	護油圈
13	93310-1014100	NEEDLE BEARING (HK1010)	4	滾針軸承
14	96411-06012-B	BOLT, FLANGE 6*12	1	凸緣螺栓
15	96414-06028-B	BOLT, FLANGE 6*28	2	凸緣螺栓
16	96510-08018-C	BOLT, SOCKET 8*18	3	六角承窩螺栓
17	97201-101805	WASHER, PLATE 10.5*18*0.5	4	平面墊圈
18	97501-03025	SPRING, STARTING CLUTCH ROLLER	3	起動離合器彈簧

TRANSMISSION,STARTER 傳動系統,起動系統					
					
NO.	PARTS NO.	PARTS NAME		QTY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	25711-RAM-00	SPROCKET DRIVE 12T	驅動鏈輪	1	
2	25716-CHP-00	PLATE, FIXING	驅動鏈輪固定板	1	
3	25757-RAM-00	GEAR, IDLE STARTER	起動惰齒輪軸襯	1	
4	26100-RAM-01	MAIN SHAFT ASS'Y	主軸總成	1	
5	26110-RAM-00	GEAR, STARTER	起動桿齒輪	1	
6	26111-CHP-00	MAIN SHAFT, TRANSMISSION 13T	傳動主軸	1	
7	26118-CHP-00	WASHER, SPLINE 2.3*26*1.6	齒輪墊圈	3	
8	26120-CHP-00	GEAR, MAIN SHAFT SECOND 17T	主軸二速齒輪	1	
9	26130-RAM-00	GEAR, MAIN SHAFT THIRD 20T	主軸三速齒輪	1	
10	26140-CHP-00	GEAR, MAIN SHAFT FOURTH 23T	主軸四速齒輪	1	
11	26150-CHP-00	GEAR, MAIN SHAFT FIFTH 25T	主軸五速齒輪	1	
12	26400-RAM-01	COUNTER SHAFT ASS'Y	副軸總成	1	
13	26410-CHP-00	GEAR, COUNTER SHAFT LOW 36T	副軸低速齒輪	1	
14	26411-CHP-00	COUNTER SHAFT, TRANSMISSION	傳動副軸	1	
15	26420-CHP-00	GEAR, COUNTER SHAFT SECOND 32	副軸二速齒輪	1	
16	26430-RAM-00	GEAR, COUNTER SHAFT THIRD 28T	副軸三速齒輪	1	
17	26440-CHP-00	GEAR, COUNTER SHAFT FOURTH 26	副軸四速齒輪	1	
18	26450-CHP-00	GEAR, COUNTER SHAFT FIFTH 24T	副軸五速齒輪	1	
19	93110-20347	OIL SEAL 20*34*7	油封	1	
20	93310-1521120	BEARING, NEEDLE HK1512	滾針軸承	1	
21	93320-153511Z	BEARING, RADIAL BALL 6202Z	滾珠軸承	1	
22	93320-2047143	BEARING, RADIAL BALL 6204C3	滾珠軸承	1	

2004.05.07


26100-RAM-01A

TRANSMISSION,STARTER 傳動系統,起動系統					
					
NO.	PARTS NO.	PARTS NAME		QTY	NOTE
項目	零件號碼	零件名稱		用量	備註
23	93320-305513M	BEARING, RADIAL BALL 6006CM	滾珠軸承	1	
24	96210-06010-B	BOLT, HEXAGON 6*10	六角螺栓	2	
25	97014-20012	CIRCLIP 20MM	C形扣環	3	
26	97201-152510	WASHER, THRUST 15.4*24.8*1	平面墊圈	1	
27	97201-153010	WASHER, THRUST 15.2*30*1	平面墊圈	1	
28	97201-172405	WASHER, THRUST 16.8*24*0.5	平面墊圈	2	
29	97201-202705	WASHER, THRUST 20.4*26.8*0.5	平面墊圈	1	
30	97201-202710	WASHER, THRUST 20.4*26.8*1	平面墊圈	1	

2004.05.07


26100-RAM-01A

CLUTCH 離合器



NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	25602-RAM-00	CLUTCH COMP	1	離合器組
2	25611-CHP-00	OUTER COMP, CLUTCH	1	離合器外套
3	25621-CHP-00	PLATE, CLUTCH PRESSURE	1	離合器壓力板
4	25622-CHP-00	DISK, CLUTCH FRICTION	4	離合器摩擦板
5	25623-CHP-00	PLATE, CLUTCH	4	離合器板
6	25627-RAM-00	DISK, CLUTCH FRICTION	1	離合器摩擦板
7	25661-CHP-00	CENTER, CLUTCH	1	離合器中心體
8	25664-CHP-00	PIN, CLUTCH LIFTER GUIDE	1	離合器舉升導銷
9	25665-CHP-00	ROD, CLUTCH LIFTER	1	離合器舉動桿
10	25670-CHP-00	PLATE, CLUTCH LIFTER	1	離合器舉升板
11	25684-RAM-00	WASHER, SPLINE	1	離合器墊圈
12	25686-RAM-00	WASHER, AWL	1	錐型彈簧墊圈
13	25688-CHP-00	WASHER, SPLINE	1	離合器墊圈
14	93320-122808M	BALL BEARING 6001CM	1	滾珠軸承
15	96414-06025-C	BOLT, FLANGE 6*25	4	凸緣螺栓
16	97010-20012	CIRCLIP 20MM	1	C型扣環
17	97501-26040	SPRING, CLUTCH	1	離合器彈簧

EXHAUST MUFFLER 排氣管



NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	31610-RAM-02C	EXHAUST MUFFLER ASS'Y	排氣管總成	1	
2	31611-RAM-00	PIPE, EXHAUST	排氣導管	1	
3	31613-CHP-00	GASKET, EXHAUST PIPE 31.5*39.5*3.5	排氣管墊片	1	
4	31614-RAM-00	GASKET, MUFFLER	消音筒墊片	1	
5	31617-CBT-02C	MUFFLER COMP	消音筒	1	
6	31618-RAM-00	PROTECTOR, EXHAUST	排氣管護罩	1	
7	31621-RAM-00	JOINT, EXHAUST PIPE	排氣管接頭	1	
8	31623-CHP-00	COLLAR, EXHAUST PIPE JOINT	排氣管接頭套筒	2	
9	95401-071007-B	NUT, FLANGE	凸緣螺帽	2	
10	96316-06010-K	SCREW, PAN HEAD	十字孔頭螺絲	2	
11	96414-08016-B	BOLT, FLANGE	凸緣螺栓	1	
12	96510-06020-K	BOLT, SOCKET	六角承窩螺栓	3	
13	97210-061215	WASHER, PLATE	石棉墊圈	4	
14	97301-061115-K	WASHER, SPRING 6.5*11*1.5	彈簧墊圈	3	