



CYLINDER HEAD 汽缸頭




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	11121-JOE-00	HEAD COMP, CYLINDER	1	汽缸頭
2	11124-JOW-00	SIDE COVER, CYLINDER HEAD	1	汽缸頭裝飾片
3	11140-JOW-00	COVER COMP, CYLINDER HEAD	1	汽缸頭蓋組
4	11141-JOW-00	COVER, CYLINDER HEAD	1	汽缸頭蓋
5	11145-JOW-00	PLATE, VENTILATION	1	通風管導板
6	11146-JOW-01	BREATHER	1	通風管接頭
7	11148-JOW-00	PIPE, VENTILATED	1	缸蓋通氣管
8	11181-JOE-00	GASKET, CYLINDER HEAD	1	汽缸頭墊片
9	11191-JOW-00	GASKET, HEAD COVER	1	汽缸頭蓋墊圈
10	11195-JOW-00	GASKET, PLATE	1	通風管導板墊片
11	43322-JOE-00	PIPE, LUBRICATION	1	油管組件
12	62210-JOW-00	PLUG, SPARK (DPR7EA NGK)	1	火星塞
13	62730-JOW-00	THERMOSTAT COMP	1	節溫器組合
14	62731-JOW-00	THERMOSTAT HULL	1	節溫器殼體
15	62732-JOW-00	THERMOSTAT COVER	1	節溫器蓋
16	62740-JOW-00	THERMO SENSOR	1	溫度感測器
17	62741-JOW-00	GROUND TERMINAL	1	接地端子
18	62745-JOW-00	THERMOSTAT	1	節溫器
19	90220-10138-B	CLIP 10*13.8	2	板型管夾
20	93210-17175	O-RING 1.7*17.5	1	護油圈
21	93210-19098	O-RING 1.9*9.8	1	護油圈
22	94410-10016	PIN, DOWEL 10*16	2	定位銷

CYLINDER HEAD 汽缸頭




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
23	94706-12010-B	BOLT	1	缸頭螺塞
24	94716-08025-R	BOLT, UNION	2	接合螺栓
25	94716-12030-R	BOLT, UNION	1	接合螺栓
26	94717-08032-C	BOLT, STUD 8*32	2	雙頭螺栓
27	96112-40818-C	SCREW, TAPPING	6	自攻螺絲
28	96318-05008-R	SCREW, PAN HEAD	2	十字孔頭螺絲
29	96411-06018-R	BOLT, FLANGE	1	凸緣螺栓
30	96411-06108-R	BOLT, FLANGE	2	凸緣螺栓
31	96414-06025-R	BOLT, FLANGE	4	凸緣螺栓
32	96416-06016-R	BOLT, FLANGE	2	凸緣螺栓
33	97230-081410	WASHER, COPPER 8.1*14*1	4	銅墊圈
34	97230-122010	WASHER, COPPER 12.6*20*1	2	銅墊圈
35	97231-061110	WASHER, ALUMINUM 6.2*11.2*1	2	鋁墊圈

PISTON, CRANKSHAFT 活塞、曲軸




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	11111-JOE-00	CYLINDER COMP	1	汽缸
2	11151-JOE-00	GASKET, CYLINDER	1	汽缸墊片
3	11400-JOE-00	CRANKSHAFT COMP	1	曲軸總成
4	11412-JOE-00	CRANK L	1	左曲軸
5	11422-JOE-00	CRANK R	1	右曲軸
6	11427-JOE-00	ROTOR, OIL	1	甩油盤
7	11451-JOE-00	ROD, CONNECTING	1	連桿
8	11481-JOE-00	PIN, CRANK	1	曲軸銷
9	11500-JOE-00	BALANCER ASS'Y	1	平衡軸總成
10	11510-JOE-00	SHAFT, BALANCER	1	平衡軸
11	11520-JOW-00	GEAR, TRANSMISSION 56T	1	平衡軸傳動齒輪組
12	11561-JOW-00	GEAR, DRIVE 56T	1	平衡軸驅動齒輪
13	11631-JOE-00	PISTON	1	活塞
14	11636-JOE-00	RING SET, PISTON	1	活塞環組
15	13178-JOW-00	OIL PUMP DRIVING WHEEL 16T	1	機油泵驅動齒輪
16	13321-CBT-00	THROUGH OIL	1	通油器
17	13324-CBT-00	SPRING, OIL THROUGH	1	通油器彈簧
18	14311-JOW-00	GEAR, TIMING DRIVE 17T	1	正時鏈輪
19	43426-JOW-00	HOSE, WATER PUMP EX	1	水泵出水管
20	90220-12217-B	CLIP 12*21.7	1	板型管夾
21	90220-12230-B	CLIP 12*23	1	板型管夾
22	93310-3240180	NEEDLE BEARING	1	滾針軸承

PISTON, CRANKSHAFT 活塞、曲軸




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
23	93321-3580213J	BALL BEARING 6307 D2/P5	2	TMB307JR2CS19-1
24	93510-121758	PIN, PISTON 12*17*57.8	1	
25	94410-10016	PIN, DOWEL 10*16	2	
26	94420-04025	KEY, WOODRUFF 25*14*4	1	
27	94510-20012	PIN, DOWEL	1	
28	94510-40005	PIN, DOWEL	1	
29	94510-40008	PIN, DOWEL	1	
30	95401-141911-C	NUT, FLANGE	1	
31	97050-10019-K	CIRCLE, PISTON PIN 1.0*19	2	
32	97201-142720	WASHER, PLATE 14.3*27.1*2	1	

WATER PUMP 水泵




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	13001-JOW-00	WATER PUMP COMP	水泵總成	1	
2	13011-JOW-00	WATER PUMP HULL	水泵本體	1	
3	13012-JOW-00	WATER PUMP COVER	水泵蓋	1	
4	13018-JOW-00	WATER SEAL A	水封A	1	
5	13021-JOW-00	WATER PUMP SHAFT	水泵軸	1	
6	13023-JOW-00	WATER SEAL B	水封B	1	
7	13024-JOW-00	FAN	水泵葉輪	1	
8	13051-JOW-00	WASHER, PUMP COVER	水泵蓋墊片	1	
9	93110-12205	OIL SEAL 12*20*5	油封	1	
10	93210-28315	O-RING 2.8*31.5	護油圈	1	
11	93320-102608	BALL BEARING 6000/P6	滾珠軸承	1	
12	93320-122406ZZ	BALL BEARING 6901ZZ/P6	滾珠軸承	1	
13	94410-08014	PIN, DOWEL 8*14	定位銷	2	
14	96411-06010-R	BOLT, FLANGE	凸緣螺栓	1	
15	96411-06025-R	BOLT, FLANGE	凸緣螺栓	2	
16	96411-06055-R	BOLT, FLANGE	凸緣螺栓	2	
17	97012-26011-K	CIRCLIP RTW-26	C形內扣環	1	
18	97230-061010	WASHER, COPPER 6.3*10.2*1	銅墊圈	1	

OIL PUMP 機油泵




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	13100-JOW-00	PUMP ASS'Y, OIL	1	機油泵總成
2	13111-JOW-00	BODY, OIL PUMP	1	機油泵本體
3	13112-JOW-00	COVER, OIL PUMP GEAR	1	機油泵齒輪蓋
4	13116-JOW-00	PLANE OIL PUMP	1	平板
5	13121-JOW-00	SHAFT, OIL PUMP	1	機油泵齒輪軸
6	13124-JOW-00	SPROCKET, OIL PUMP DRIVEN 25T	1	機油泵驅動齒輪
7	13131-JOW-00	CHAIN, OIL PUMP 6.35*46	1	機油泵驅動鏈條
8	13141-JOW-00	ROTOR, OIL PUMP INNER	1	機油泵內轉子
9	13142-JOW-00	ROTOR, OIL PUMP OUTER	1	機油泵外轉子
10	94510-40007	PIN, DOWEL Ø4*6.5	1	滾針
11	96310-03008-C	SCREW, PAN HEAD	1	十字孔頭螺絲
12	96411-06012-C	BOLT, FLANGE	2	凸緣螺栓
13	96411-06028-B	BOLT, FLANGE	2	凸緣螺栓
14	97010-10010-K	CIRCLIP 10*1	1	C形扣環

CARBURETOR 化油器




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	13201-CEE-00	CARBURETOR ASS'Y	化油器總成	1	
2	13240-CEE-00	JET, MAIN #108	主噴口	1	
3	13242-CHH-00	JET, GUIDE #38	引導噴口	1	
4	13555-JOW-00	MANIFOLD, INTAKE	進氣歧管	1	
5	13620-CHH-00	INSULATOR, CARBURETOR	化油器隔熱板	1	
6	13621-CBT-00	GASKET, CARBURETOR INSULATOR	隔熱板墊片	1	
7	93210-24333	O-RING 2.4*33.3	護油圈	1	
8	93210-30335	O-RING 3*33.5	護油圈	1	
9	94717-06037-B	BOLT, STUD 6*37	雙頭螺栓	4	
10	95401-061006-C	NUT, FLANGE	凸緣螺帽	4	

INTAKE 空氣吸入口




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	13411-CFS-00	CASE, AIR CLEANER	1	空氣濾清器箱
2	13412-JOW-00	CAP, CLEANER CASE	1	空氣濾清器箱蓋
3	13432-RAM-00	SEAL, ELEMENT	1	濾網固定板封圈
4	13433-RAM-00	PLATE, ELEMENT SET	2	濾清網固定板
5	13437-CRS-00	DUCT	1	防塵管
6	13451-RAM-00	ELEMENT, AIR CLEANER	1	空氣濾清網
7	13452-RAM-00	SEAL, AIR CLEANER COVER	1	濾清箱封圈
8	13453-JOW-01	JOINT, AIR CLEANER	1	濾清箱接頭
9	90260-80047	CLAMP, HOSE	1	連接管管夾
10	96110-43018-K	SCREW, TAPPING	8	自攻螺絲
11	96313-06020-K	SCREW, PAN HEAD WITH WASHER	4	十字孔頭螺絲附墊圈
12	96318-06012-G	SCREW, PAN HEAD	1	十字孔頭螺絲
13	96414-06020-B	BOLT, FLANGE	4	凸緣螺栓

OIL CATCH BOX 集油室




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	13420-JOW-00	OIL CATCH ASS'Y	1	集油室總成
2	13421-JOW-00	BOX OIL CATCH	1	集油室箱
3	13422-JOW-00	COVER OIL CATCH	1	集油室蓋
4	13423-JOW-00	SEAL OIL CATCH	1	集油室封圈
5	13427-JOW-00	FILTER OIL CATCH	1	集油濾清海綿
6	13491-CRS-00	PLUG BREATHER TUBE	1	集油管塞
7	90210-12012	CLIP	2	管夾
8	90311-80120310	TUBE VINYL	1	集油管
9	96110-31224-K	SCREW, TAPPING	3	自攻螺絲
10	96414-06016-B	BOLT, FLANGE	2	凸緣螺栓

CAMSHAFT, VALVE 凸輪軸,閥門




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	11131-JOW-00	HOLDER, CAMSHAFT	凸輪軸固定座	1	
2	14110-JOE-00	CAMSHAFT COMP	凸輪軸整體	1	
3	14430-JOW-00	HOLDER COMP, ROCKER ARM	搖臂座組	1	
4	14431-JOW-00	ARM, VALVE ROCKER	門閥搖臂	2	
5	14436-CBT-00	SCREW, TAPPET ADJUSTING	挺桿調整螺絲	2	
6	14437-CBT-00	NUT, TAPPET ADJUSTING	挺桿調整螺帽	2	
7	14450-JOW-00	SHAFT, IN ROCKER ARM	進氣閥搖臂軸	1	
8	14452-JOW-00	SHAFT, EX ROCKER ARM	排氣閥搖臂軸	1	
9	14711-JOW-00	VALVE, IN	進氣閥門	1	
10	14721-JOW-00	VALVE, EX	排氣閥門	1	
11	14731-CBT-00	SEAL, VALVE STEM	閥門徑封	2	
12	14751-JOW-00	SPRING, VALVE OUTER 2.5*22*41.5	閥門外彈簧	2	
13	14761-JOW-00	SPRING, VALVE INNER 1.9*16.2*31	閥門內彈簧	2	
14	14771-JOW-00	RETAINER, VALVE SPRING	閥門彈簧承盤	2	
15	14781-JOW-00	COTTER, VALVE	閥門鎖扣	4	
16	94410-10016	PIN, DOWEL 10*16	定位銷	2	
17	95401-081208-C	NUT, FLANGE	凸緣螺帽	4	
18	97201-081822-B	WASHER, PLATE 8.6*17.8*2.2	平面墊圈	4	
19	97201-162308	SEAT, VALVE SPRING OUTER 16.6*23*0.8	彈簧座	2	

CAM CHAIN, TENSIONER 內鏈條、拉力桿




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	14501-JOE-00	CHAIN, CAM 100L	凸輪軸內鏈條	1	
2	14510-JOE-00	TENSIONER, CAM CHAIN	鏈條拉力桿	1	
3	14520-JOW-00	LIFTER ASS'Y, TENSIONER	鏈條調整器	1	
4	14523-JOW-00	GASKET, TENSIONER LIFTER	鏈條調整器墊片	1	
5	14531-JOW-00	PIVOT, CAM CHAIN TENSIONER	拉力桿螺絲	1	
6	14560-JOE-00	GUIDE COMP, CAM CHAIN	鏈條導件	1	
7	93210-15095	O-RING 1.5*9.5	護油圈	1	
8	96316-06006-R	SCREW, PAN HEAD	十字孔頭螺絲	1	
9	96411-06022-R	BOLT, FLANGE	凸緣螺栓	2	

CRANKCASE 曲軸箱




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	11146-JOW-00	BREATHER	1	通風管接頭
2	13424-JOW-00	BREATHER TUBE	1	集油室通氣管
3	15111-JOW-00	CRANKCASE, LEFT	1	左曲軸箱
4	15130-JOW-00	SELECTOR SWITCH	1	檔位開關組
5	15136-JOW-00	GROMMET	1	檔位開關密封套
6	15172-JOW-00	HOSE, BREATH	1	變速箱蓋通氣管
7	15174-JOW-00	PLATE, BEARING	2	軸承壓板
8	15211-JOE-00	CRANKCASE, RIGHT	1	右曲軸箱
9	15251-JOW-00	GASKET, CRANKCASE	1	曲軸箱墊片
10	15533-JOW-00	CAP, TAPPET ADJUSTING HOLE	1	濾油網螺帽蓋
11	15536-JOW-00	SCREEN, OIL FILTER	1	濾油網
12	15538-JOW-00	SPRING, OIL FILTER SCREEN	1	濾油網彈簧
13	15541-CHP-00	CLAMPER, WIRE HARNESS	2	配線固定板
14	24228-JOW-00	BOLT 14*21	1	換檔定位螺栓
15	43535-JOW-00	JOINTER, THREE WAY	1	三向管接頭
16	90220-10138-B	CLIP 10*13.8	5	板型管夾
17	93110-14225	OIL SEAL TC 14*22*5	1	油封
18	93110-25408	OIL SEAL TC 25*40*8	1	油封
19	93110-27427	OIL SEAL TC 27*42*7	1	油封
20	93210-24176	O-RING 2.4*17.6	1	護油圈
21	93210-30305	O-RING 3*30.5	1	護油圈
22	93310-2026160	NEEDLE BEARING (HK 2016)	1	滾針軸承

CRANKCASE 曲軸箱




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
23	93320-204714	BALL BEARING 6204/P5	1	
24	93320-2552153	BALL BEARING 6205/C3	2	6205CM
25	93320-256217	BALL BEARING 6305/P53	1	6305CM
26	94410-10016	PIN, DOWEL 10*16	2	
27	94520-09500	BALL Ø9.5	1	
28	94717-08218-C	BOLT, STUD	2	
29	94717-08225-C	BOLT, STUD	2	
30	96411-06010-R	BOLT, FLANGE	1	
31	96411-06012-R	BOLT, FLANGE	2	
32	96411-06050-R	BOLT, FLANGE	4	
33	96510-06010-C	BOLT, SOCKET	2	
34	97230-142310	WASHER, COPPER 14.1*22.6*1	1	
35	97501-1008024	SPRING, COMPRESSION 1*7.5*23.5	1	

GEARBOX COVER 變速箱蓋




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	15311-JOW-00	COVER, GEARBOX	變速箱蓋	1	
2	15351-JOW-00	GASKET, GEARBOX COVER	變速箱蓋墊片	1	
3	32191-JOW-00	DRIVE CHAIN CASE	鏈條蓋	1	
4	32194-JOW-00	BRACKET, CHAIN CASE	鏈條蓋支架	1	
5	45836-JOW-00	CONNECT, SPEEDOMETER CABLE	速度錶鋼索接頭	1	
6	45838-CJW-00	GEAR, SPEEDOMETER 9T	速度表齒輪	1	
7	93110-06147	OIL SEAL	油封	1	
8	93110-14287	OIL SEAL TC 14*28*7	油封	1	
9	94410-10016	PIN, DOWEL 10*16	定位銷	2	
10	96108-51616-K	SCREW, TAPPING	自攻螺絲	2	
11	96411-06016-R	BOLT, FLANGE	凸緣螺栓	3	
12	96414-08035-C	BOLT, FLANGE	凸緣螺栓	7	
13	96414-08040-C	BOLT, FLANGE	凸緣螺栓	2	
14	96414-12015-C	BOLT, FLANGE	凸緣螺栓	1	
15	96416-08012-C	BOLT, FLANGE	凸緣螺栓	1	
16	97201-051010	WASHER, PLATE	速度表齒輪襯片	1	
17	97201-061410-C	WASHER, PLATE 6.7*14*1	平面墊圈	1	
18	97201-202610-C	WASHER, PLATE 20.2*26*1	平面墊圈	1	
19	97231-081620	WASHER, ALUMINUM 8.2*16*2	鋁墊圈	1	
20	97231-122118	WASHER, ALUMINUM 12.5*20.6*1.8	鋁墊圈	1	

CRANKCASE COVER 機箱蓋




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	15411-JOW-00	COVER, CRANKCASE	1	機箱蓋
2	15432-JOW-00	COVER, RE-COILED STARTER	1	啓動器蓋
3	15433-JOW-00	PIPE, VENTILATION IN	1	機箱蓋進氣導管
4	15434-JOW-00	PIPE, VENTILATION EX	1	機箱蓋排氣導管
5	15481-JOW-00	GASKET, CRANKCASE COVER	1	機箱蓋墊片
6	15483-JOW-00	GASKET, COVER	1	啓動器蓋墊片
7	15491-GAT-00	CLAMP, HOSE	1	導管束帶
8	15494-JOW-00	CLAMP, HOSE	1	導管束帶
9	22600-JOW-00	RE-COILED STARTER ASS'Y	1	手拉啓動器組
10	22603-JOW-00	CORD WHEEL SET	1	繩輪組件
11	22605-JOW-00	SPRING	1	發條彈簧
12	22606-JOW-00	SPRING TRAY	1	發條盤
13	22621-JOW-00	PULLER	1	手柄
14	22623-JOW-00	CAP, PULLER	1	手柄蓋
15	22626-JOW-00	CORD, RE-COILED STARTER	1	起動繩
16	22630-JOW-00	CAM, STARTER	2	啓動爪
17	22636-JOW-00	SCREW, FIXING 6*22.5	1	定位螺絲
18	22638-JOW-00	DIRECTION TRAY	1	導向盤
19	93320-254712BB	BALL BEARING 6005 2RZ	1	滾珠軸承
20	94410-08014	PIN, DOWEL	2	定位銷
21	94410-10016	PIN, DOWEL 10*16	2	定位銷
22	96110-41516-B	SCREW, TAPPING	2	自攻螺絲

CRANKCASE COVER 機箱蓋




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
23	96318-06012-G	SCREW, PAN HEAD	十字孔頭螺絲	2	
24	96411-06025-R	BOLT, FLANGE	凸緣螺栓	3	
25	96411-06028-R	BOLT, FLANGE	凸緣螺栓	8	
26	96411-06032-R	BOLT, FLANGE	凸緣螺栓	2	
27	96411-06040-R	BOLT, FLANGE	凸緣螺栓	2	
28	97011-06010-K	CIRCLIP 6*10	E形扣環	2	
29	97012-47015-K	CIRCLIP 47*1.5	C形內扣環	1	
30	97321-061825-G	WASHER, FLANGE	凸緣墊圈	2	
31	97501-1513010	SPRING	彈簧	1	
32	97508-0708150-	SPRING, TORSION	扭轉彈簧	2	

RIGHT CRANKCASE COVER 右曲軸箱蓋




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	12655-JOW-00	CAP, A.C.G 14*7	A.C.G 蓋	1	
2	15221-JOW-00	COVER, R CRANKCASE COMP	右曲軸箱蓋墊片	1	
3	15511-JOW-00	GASKET, R CRANKCASE COVER	右曲軸箱蓋	1	
4	15551-JOW-00	MIRROR, OIL	油鏡組件	1	
5	15553-JOW-00	PLATE, MIRROR OIL	油鏡壓板	1	
6	15563-JOW-00	GAUGE, OIL LEVEL	量油尺	1	
7	93210-24140	O-RING 2.4*14	護油圈	1	
8	93210-35178	O-RING 3.55*17.8	護油圈	1	
9	94410-10016	PIN, DOWEL 10*16	定位銷	2	
10	96411-06035-R	BOLT, FLANGE	凸緣螺栓	2	
11	96411-06045-R	BOLT, FLANGE	凸緣螺栓	2	
12	96411-06125-R	BOLT, FLANGE	凸緣螺栓	6	
13	96411-06135-R	BOLT, FLANGE	凸緣螺栓	2	
14	96414-12015-C	BOLT, FLANGE	凸緣螺栓	1	
15	96510-06010-C	BOLT, SOCKET	六角承窩螺栓	1	
16	97231-122118	WASHER, ALUMINUM 12.5*20.6*1.8	鋁墊圈	1	

STARTING MOTOR 起動系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	12638-JOW-00	FLODER	1	檔顯器導線夾
2	23524-JOW-00	GEAR COMP, STARTING CLUTCH 53T	1	起動輪
3	23570-JOW-00	STARTING CLUTCH ASS'Y	1	起動離合器總成
4	23612-JOW-00	GEAR, IDLE 54/11T	1	惰齒輪
5	35550-JOW-00	FLYWHEEL COMP	1	轉子總成
6	35560-JOW-00	STATOR COMP	1	發電機座總成
7	35800-JOW-00	MOTOR ASS'Y, STARTER	1	起動馬達總成
8	35831-JOW-00	CABLE, STARTER MOTOR	1	起動馬達導線
9	94510-100040	SHAFT, IDLE GEAR 10*39.5	1	惰齒輪軸
10	96210-05028-C	BOLT, HEXAGON	3	六角螺栓
11	96310-05016-C	SCREW, PAN HEAD	2	十字孔頭螺絲
12	96411-06022-R	BOLT, FLANGE	2	凸緣螺栓
13	96510-08016-C	BOLT, SOCKET	3	六角承窩螺栓

GEAR SHIFT 變速機構




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	24206-JOW-00	SHIFT LEVER	1	變速拉桿
2	24210-JOW-00	GEAR SHIFT LEVER LOWER	1	變速桿總成
3	24220-JOW-01	DRUM, GEAR SHIFT	1	齒輪變速筒
4	24221-JOW-00	SHAFT, GEAR SHIFT DRUM	1	齒輪變速筒軸
5	24236-JOW-00	SHAFT, GEAR SHIFT FORK 12*94	1	變速叉樞軸
6	24238-JOW-00	FORK, GEAR SHIFT	1	齒輪變速叉
7	93510-142207	BUSH, GEAR SHIFT DRUM	1	齒輪變速筒襯套
8	96210-06020-C	BOLT, HEXAGON	1	六角螺栓
9	97010-22010-K	CIRCLIP	1	C形扣環
10	97011-10010-K	CIRCLIP	1	E形扣環
11	97011-12010-K	CIRCLIP	2	E形扣環
12	97011-12012-K	CIRCLIP 12*1.2	2	E形扣環
13	97201-142005	WASHER, PLATE 15.2*25.6*2.0	4	平面墊圈
14	97501-2320025	SPRING, COMPRESSION	2	壓縮彈簧

CLUTCH 離合器




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	25602-JOW-00	PULLEY ASS'Y, DRIVEN	副槽輪總成	1	
2	25611-JOW-00	OUTER, CLUTCH	離合器殼整體	1	
3	25711-JOW-00	FACE, DRIVE	主固定槽輪	1	
4	25720-JOW-00	FACE COMP, MOVABLE DRIVE	主滑動槽輪整體	1	
5	25723-JOW-00	PLATE, RAMP	凸輪板	1	
6	25732-JOW-00	ROLLER SET, WEIGHT 25g	重錘滾子	6	
	25732-JOW-01	ROLLER SET, WEIGHT 23.5g	重錘滾子	6	
7	25741-JOW-00	BELT, DRIVE 893*24*30*10.5	皮帶	1	
8	25753-JOW-00	PIECE, SLIDE	滑件	3	
9	25757-JOW-00	CLUTCH, ONE-WAY	單向離合器	1	
10	93510-192763	BOSS, DRIVE FACE 19.1*27*62.8	主滑動槽輪襯套	1	
11	95401-121711-C	NUT, FLANGE	凸緣螺帽	1	
12	95401-141911-C	NUT, FLANGE	凸緣螺帽	1	
13	97310-142826	WASHER, CONICAL SPRING 14.2*28*2.6/3.6	錐形彈簧墊圈	1	

TRANSMISSION, STARTER 傳動系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	25713-JOW-01	SPROCKET DRIVE 520-13T	1	驅動鏈輪
2	25716-JOW-00	PLATE, FIXING	1	驅動鏈輪固定板
3	26111-JOW-00	GEAR, PRIMARY DRIVE 17T	1	主驅動軸
4	26410-JOW-00	MAIN AXLE COMP	1	惰輪軸總成
5	26411-JOW-00	GEAR, IDLE 23T/5T	1	惰輪軸
6	26412-JOW-00	GEAR, FORWARD 45T	1	前進齒輪
7	26413-JOW-00	WASHER, SPLINE 23.2/25.2*39.9*1.4	1	齒輪墊圈
8	26415-JOW-00	AXLE, IDLE GEAR 21T	1	倒檔惰齒輪軸
9	26415-JOW-00A	IDLE GEAR AXLE ASS'Y	1	倒檔惰齒輪軸總成
10	26416-JOW-00	IDLE GEAR, REVERSE 49T	1	倒檔惰齒輪
11	26420-JOW-00	DRIVE AXLE ASSEMBLY 36T	1	傳動軸總成
12	26426-JOW-00	GEAR, REVERSE 37T	1	倒檔齒輪
13	26430-JOW-00	CLUTCH, DOG	1	變檔鼓
14	93110-30407	OIL SEAL TC 30*40*7	1	油封
15	93310-2533160	NEEDLE BEARING NK25/16	1	滾針軸承
16	93310-3042170	NEEDLE BEARING NA-RNA4905	1	滾針軸承
17	93320-204714	BALL BEARING 6204/P53	1	滾珠軸承
18	93320-2052153	BALL BEARING 6304/C3P6	1	滾珠軸承
19	93320-255215BB	BALL BEARING 6205 2RZ	1	滾珠軸承
20	93510-202211	BOSS, DRIVE FACE 20*22*11.2	1	前進齒輪襯套
21	93510-202311-K	BOSS, DRIVE FACE 20*23*10.6	1	軸套
22	96210-06016-C	BOLT, HEXAGON	2	六角螺栓

TRANSMISSION, STARTER 傳動系統




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
23	97010-25012-K	CIRCLIP 25*1.2	2	C形扣環
24	97012-52020-K	CIRCLIP 52*2	1	C形內扣環
25	97014-25012-K	CIRCLIP 25*1.2	1	C形扣環
26	97201-202710-K	WASHER, PLATE 20.2*26.9*1	2	止推墊片
27	97201-203310-K	WASHER, PLATE 20.2*32.9*1	1	平面墊圈
28	97201-254010-K	WASHER, PLATE 25.2*39.9*1	1	止推墊片

AIR INJECTION SYSTEM 二次空氣系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	11126-JOW-00	PIPE, AIR INJECTION	二次空氣導管	1	
2	11128-JOW-00	GASKET, PIPE AIR INJECTION	二次空氣導管墊片上	1	
3	11129-JOW-00	GASKET, PIPE AIR INJECTION	二次空氣導管墊片下	1	
4	31681-JOW-00	AIR INJECTION, PULSE AIR	截止閥	1	
5	31683-JOW-00	VALVE, ONE WAY	單向閥蓋	1	
6	31684-JOW-00	CAP, VALVE	單向閥	1	
7	31688-JOW-00	HOSE, AIR INJECTION EX	截止閥輸出管	2	
8	90212-10074-C	CLIP 1*7.4	管夾	2	
9	90220-12178-B	CLIP 12*Ø17.8	板型管夾	3	
10	90310-42550	HOSE, VALUUM	截止閥負壓管	1	
11	96411-06018-R	BOLT, FLANGE	凸緣螺栓	2	
12	96411-06025-R	BOLT, FLANGE	凸緣螺栓	1	
13	96411-06040-R	BOLT, FLANGE	凸緣螺栓	2	

WATER-COOLING SYSTEM 水冷卻系統



NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	43400-JOW-00	RADIATOR ASS'Y	1	水箱總成
2	43410-JOW-00	RADIATOR	1	水箱
3	43411-JOW-00	BRACKET, RADIATOR	1	水箱上支架
4	43416-JOW-00	BRACKET, RADIATOR	1	水箱下支架
5	43420-JOW-00	HOSE, RADIATOR IN	1	水箱進水管
6	43423-JOW-00	HOSE, RADIATOR CAP	1	加水口水管
7	43425-JOW-00	HOSE, WATER PUMP IN	1	水泵進水管
8	43428-JOW-00	HOSE, WATER CIRCULATE	1	冷水循環管
9	43430-JOW-00	RADIATOR CAP	1	水箱蓋
10	43435-JOW-00	HULL, RADIATOR CAP	1	水箱蓋體
11	43440-JOW-00	RADIATOR DEFEND	1	水箱護罩
12	43450-JOW-00	FAN MOTOR ASS'Y	1	風扇馬達總成
13	43451-JOW-00	FAN MOTOR COMP	1	風扇馬達組
14	43456-JOW-00	BRACKET, FAN		風扇支架
15	43460-JOW-00	WATER TANK	1	副水箱
16	43463-JOW-00	HOSE 1, WATER TANK	1	副水箱溢流管
17	43466-JOW-00	CAP, WATER TANK	1	副水箱蓋
18	43468-JOW-00	HOSE 2, WATER TANK	1	副水箱通氣管
19	62750-JOW-00	FAN MOTOR SWITCH	1	風扇開關
20	90212-10074-C	CLIP 1*7.4	1	管夾
21	90212-12085-C	CLIP 1.2*8.5	1	管夾
22	90212-12095-C	CLIP 1.2*9.5	1	管夾

WATER-COOLING SYSTEM 水冷卻系統



NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
23	90220-08100-B	CLIP 8*10	2	板型管夾
24	90220-12198-B	CLIP 12*19.8	2	板型管夾
25	90220-12217-B	CLIP 12*21.7	1	板型管夾
26	90220-12230-B	CLIP 12*23	3	板型管夾
27	93530-060911-K	COLLAR	2	水箱軸環
28	93580-092212	GROMMET	2	水箱套環
29	93580-102212	GROMMET	2	牌照板套環
30	96218-06012-C	BOLT, HEXAGON	4	六角螺栓
31	96218-06016-B	BOLT, HEXAGON	2	六角螺栓
32	96218-06020-C	BOLT, HEXAGON	3	六角螺栓
33	96310-04010-B	SCREW, PAN HEAD	2	十字孔頭螺絲
34	96414-06012-B	BOLT, FLANGE	1	凸緣螺栓
35	96414-06022-B	BOLT, FLANGE	2	凸緣螺栓
36	96616-05012-K	BOLT, HEXAGON WITH WASHER	4	六角十字穴螺栓附墊圈
37	97201-040908-B	WASHER, PLATE 4.2*8.8*0.8	3	平面墊圈