



EXHAUST MUFFLER 排氣管




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	31610-CJW-00	EXHAUST MUFFLER ASSY	排氣管總成	1	
	31610-CJW-00C	EXHAUST MUFFLER ASSY	排氣管總成	1	EEC
	31610-CJW-01	EXHAUST MUFFLER ASSY	排氣管總成	1	Alloy
2	31611-CJW-00	PIPE, EXHAUST	排氣導管	1	
3	31613-JOW-00	GASKET, EXHAUST PIPE (29*36*4.8)	排氣管墊片	1	
4	31614-CEW-00	GASKET, MUFFLER	消音筒墊片	1	
5	31617-CJW-00	MUFFLER COMP	消音筒	1	
6	31618-RAM-00	PROTECTOR, EXHAUST	排氣管護罩	1	
7	31624-CEW-00	CLIP	消音筒管束	1	
8	95401-081208-B	NUT, FLANGE	凸緣螺帽	2	
9	96316-06010-K	SCREW, PAN HEAD	十字孔頭螺絲	2	
10	96414-08016-B	BOLT, FLANGE	凸緣螺栓	1	
11	97210-061215	WASHER, PLATE	石棉墊圈	4	

REAR ARM 擺動臂




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	32100-CJW-00	REAR ARM	1	擺動臂
2	32115-RAM-00	BUSH	2	擺動臂軸襯
3	32116-RAM-00	SPACER	1	擺動臂隔筒
4	32118-RAM-00	COVER, THRUST	2	擺動臂塵封蓋
5	32119-RAM-00	OIL SEAL	2	擺動臂防塵封
6	32160-RAM-00	SEAL, GUARD	1	鏈條導環
7	32165-CJW-00	SUPPORT, CHAIN	1	鏈條支持塊
8	32190-JOW-00	COVER	1	下護蓋
9	93210-25200	O-RING 2.5*20	2	護油圈
10	93310-222820	NEEDLE BEARING HK-2220	2	滾針軸承
11	94610-15258-B	SHAFT, PIVOT	1	擺動臂軸
12	95301-142212-B	NUT, LOCK	1	止鬆螺帽
13	96414-08012-B	BOLT, FLANGE	4	凸緣螺栓
14	96414-08040-B	BOLT, FLANGE	2	凸緣螺栓
15	97201-142820-B	WASHER, PLATE 14.2*28.4*2.0	1	平面墊圈
16	97201-243820	WASHER, PLATE	2	平面墊圈

REAR SUSPENSION 後懸吊系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	32210-CEW-01	SHOCK ABSORBER ASSY, REAR	後緩衝器總成	1	
2	32231-RAM-00	COVER, THRUST	防塵墊片	2	
3	90240-29025-B	COTTER PIN 2.9*25	開口銷	1	
4	94610-12070-B	PIN, CLEVIS	後緩衝器固定銷	1	
5	94710-10066-B	BOLT	後緩衝器固定軸	1	
6	95311-101710-B	NUT, NYLON	尼龍螺帽	1	
7	97201-102220-B	WASHER, PLATE 10.5*22*2	平面墊圈	1	
8	97201-122223-B	WASHER, PLATE 12.5*22*2.3	平面墊圈	1	

FRAME 車架




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	32167-RAM-00	TENSIONER	拉緊環	2	
2	32168-RAM-00	BUSH	拉緊環軸襯	2	
3	41110-CJW-01	FRAME COMP	車架整體	1	silver color
	41110-CJW-0102	FRAME COMP	車架整體	1	red color
4	41154-RAM-00	PLUG, SPECIAL SHAPE	管塞	2	
5	41181-CJW-00	ENGINE HANGER FRONT	引擎前固定座	1	
6	41199-CJW-00	GUARD	車架底板	1	
7	46412-RAM-00	BUSH, SOLID	轉向桿襯套	2	
8	93210-24148	O-RING 2.4*14.8	護油圈	2	
9	94340-06010-B	NIPPLE, GREASE M6*P1.0	黃油嘴	1	
10	94610-10158-B	BOLT	前輪軸	1	
11	95101-061820-C	NUT, SPRING	U型板螺帽	1	
12	95311-101710-B	NUT, NYLON	尼龍螺帽	3	
13	96414-06012-B	BOLT, FLANGE	凸緣螺栓	4	
14	96414-06016-B	BOLT, FLANGE	凸緣螺栓	1	
15	96414-08012-B	BOLT, FLANGE	凸緣螺栓	2	
16	96414-10016-B	BOLT, FLANGE	凸緣螺栓	4	
17	96414-10085-B	BOLT, FLANGE	凸緣螺栓	2	
18	97201-082420-B	WASHER, PLATE 8.7*24*2.0	平面墊圈	2	
19	97321-061825-G	WASHER, FLANGE	凸緣墊圈	4	

BUMPER 保護桿




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	41601-CJW-00	SHIELD, FRONT	前保護桿	1	
2	51175-CGW-00	STAY COVER, L	後蓋左固定座	1	
3	51176-CGW-00	STAY COVER, R	後蓋右固定座	1	
4	52850-CEW-00	SHIELD, REAR	後保護桿	1	
5	95201-061005-B	NUT, HEXAGON	六角螺帽	2	
6	96318-06020-G	SCREW, PAN HEAD	十字孔頭螺絲	2	
7	96414-08016-B	BOLT, FLANGE	凸緣螺栓	7	
8	96414-08020-B	BOLT, FLANGE	凸緣螺栓	1	
9	97301-061215-B	WASHER, SPRING	彈簧墊圈	2	
10	97321-061825-G	WASHER, FLANGE	凸緣墊圈	2	

STEERING 轉向裝置




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	42101-APJ-00	COLUMN, STEERING	轉向桿	1	
2	42106-SK9-00	BRIDGE, TOP	頂樑	1	
3	42111-RAM-00	PLUG, TAPER	塞子	1	
4	42118-AAM-00	BRACKET, STEERING LOWER	導線環	1	
5	42140-CGV-01	ROD, TIE ASSY	連桿總成	2	
6	42141-CGV-01	ROD, TIE	連桿	2	
7	42142-RAM-00	JOINT, UNIVERSAL 1	萬向接頭 內	2	
8	42143-RAM-00	JOINT, UNIVERSAL 2	萬向接頭 外	2	
9	42146-RAM-00	NUT	連桿螺帽	2	
10	46125-RAM-00	HOLDER, HANDLE UPPER	把手上固定座	2	
11	46411-RAM-00	BEARING, STEERING	轉向桿固定座	2	
12	46416-RAM-00	WASHER, LOCK	制止片	1	
13	46417-RAM-00	OIL SEAL	轉向桿封圈	2	
14	90240-23020-B	COTTER PIN 2.3*20	開口銷	5	
15	93510-081442-C	COLLAR	轉向桿座隔管	2	
16	95201-101408-C	NUT, HEXAGON	六角螺帽	2	
17	95321-101710-C	NUT, CASTLE	有槽螺帽	4	
18	95401-101409-B	NUT, FLANGE	凸緣螺帽	1	
19	96210-08060-B	BOLT, HEXAGON	六角螺栓	2	
20	96414-08050-B	BOLT, FLANGE	凸緣螺栓	4	
21	97201-101805-B	WASHER, PLATE	平面墊圈	2	
22	97201-102620-B	WASHER, PLATE	平面墊圈	1	
23	97301-101825-B	WASHER, SPRING	彈簧墊圈	1	

FRONT SUSPENSION 前懸吊系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	QTY 用量	NOTE 備註
1	42126-CGW-01	SHOCK ABSORBER ASSY	2	前緩衝器總成
2	42150-CGV-00	UNIVERSAL JOINT COMP	4	萬向接頭組
3	42161-CGV-02	FRONT LOWER, ARM LEFT	1	左前下搖臂
4	42161-CGV-02G	FRONT LOWER, ARM LEFT	1	左前下搖臂
5	42163-RAM-00	COLLAR	4	下搖臂軸襯
6	42166-CGV-02	FRONT UPPER, ARM LEFT	1	左前上搖臂
7	42166-CGV-02G	FRONT UPPER, ARM LEFT	1	左前上搖臂
8	42171-CGV-02	FRONT LOWER, ARM RIGHT	1	右前下搖臂
9	42171-CGV-02G	FRONT LOWER, ARM RIGHT	1	右前下搖臂
10	42173-RAM-00	COLLAR	2	上搖臂軸襯
11	42176-CGV-02	FRONT UPPER, ARM RIGHT	1	右前上搖臂
12	42176-CGV-02G	FRONT UPPER, ARM RIGHT	1	右前上搖臂
13	42183-RAM-00	COVER, THRUST	12	塵封蓋
14	93330-152118	BUSH, SOLID	12	羅龍滑動軸承
15	94340-06010-B	NIPPLE, GREASE M6*P1.0	6	黃油嘴
16	94610-10208-B	SHAFT, PIVOT	2	上搖臂固定軸
17	95311-101710-B	NUT, NYLON	10	尼龍螺帽
18	96414-10055-B	BOLT, FLANGE	4	凸緣螺栓
19	96414-10080-B	BOLT, FLANGE	4	凸緣螺栓
20	97010-30015-K	CIRCLIP	4	C型扣環
21	97201-102020-B	WASHER, PLATE 10.5*20*2	2	平面墊圈

FRONT WHEEL 前輪




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	42515-RAM-00	SPACER, BEARING	2	
2	42570-CBW-00	VALVE, RIM	2	for alloy
	42570-RAM-00	VALVE, RIM	2	
3	42581-CGV-00	HUB, FRONT	2	
4	42582-CBW-02	WHEEL, FRONT AT10*5.5AT	2	alloy
	42582-RAM-00	WHEEL, FRONT AT10*5.5AT	2	
5	42590-CGV-02	TIRE, FRONT 165/70-10	2	
6	90240-29025-B	COTTER PIN 2.9*25	2	
7	93110-22357	OIL SEAL TC 22*35*7	2	
8	93110-30424	OIL SEAL TC 30*42*4.5	2	
9	93320-153511S	BALL BEARING 6202 CS05/2A	2	
10	93320-204212M	BALL BEARING 6004CM/2A	2	
11	93510-152209-C	COLLAR	2	
12	93510-203006-C	SPACER, BEARING	2	
13	94710-10037-C	BOLT, RIBBED NECK	8	for alloy
	94710-10032-C	BOLT, RIBBED NECK	8	
14	95321-142215-C	NUT, CASTLE	2	
15	95801-101718-C	LOCK NUT, FLANGE	8	for alloy
	95401-101409-C	NUT, FLANGE	8	
16	97201-142820-C	WASHER, PLATE 14.2*28.4*2	2	

REAR HUB 後輪轂




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	25741-CEW-00	CHAIN 520RO-94L	鏈條	1	
2	25742-CEW-00	JOINT, CHAIN 520RO	鏈條接頭	1	
3	32120-RAM-00	ADJUSTER, CHAIN	鏈條調整器	2	
4	42812-CJE-00	SPROCKET, DRIVEN 520-33T	傳動鏈輪	1	
5	42815-RAM-00	SPACER, BEARING	後輪隔管	1	
6	42821-RAM-01	DRIVE SPROCKET BASE	傳動鏈輪座	1	
7	42835-CJW-01	AXLE, WHEEL	後輪軸	1	
8	42836-RAM-00	SPACER, SPROCKET	傳動鏈輪隔管	1	
9	42881-CFS-00	HUB, REAR	後輪轂	1	
10	93110-42628	OIL SEAL 42*62*8	油封	1	
11	93110-44628	OIL SEAL 44*62*8	油封	1	
12	93320-356214	BALL BEARING 6007/2A	滾珠軸承	2	
13	94610-10174-B	BOLT	後輪轂固定軸	1	
14	94610-10178-B	BOLT	後輪轂固定軸	1	
15	94706-10020-C	BOLT, BUTTON	剎車圓盤固定螺栓	4	
16	95201-081207-B	NUT, HEXAGON	六角螺帽	2	
17	95201-335014-C	NUT, HEXAGON	六角螺帽	2	
18	95311-101710-B	NUT, NYLON	尼龍螺帽	2	
19	96210-08055-B	BOLT, HEXAGON	六角螺栓	2	
20	97201-102620-B	WASHER, PLATE 10.3*26*2.0	平面墊圈	4	

REAR WHEEL 後輪




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	42570-CBW-00	VALVE, RIM	氣門嘴	2	for alloy
	42570-RAM-00	VALVE, RIM	氣門嘴	2	
2	42882-CBT-00	WHEEL, REAR 10*8AT	後輪圈	2	
	42882-CBW-01	WHEEL, REAR 10*8AT	後輪圈	2	alloy
3	42885-CBT-00	COLLAR, WHEEL	後輪固定座	2	
4	42890-CGV-04	TIRE, REAR 225/40-10 K547 6P 34N	後輪胎	2	
5	90240-29025-B	COTTER PIN 2.9*25	開口銷	2	
6	94710-10037-C	BOLT, RIBBED NECK	輪圈固定螺栓	8	
7	95326-142114-C	NUT, CASTLE FLANGE	有槽凸緣螺帽	2	
8	95801-101718-C	LOCK NUT, FLANGE	鎖位凸緣螺帽	8	
9	97201-143240-C	WASHER, PLATE 14.2*32.5*4.0	平面墊圈	2	

FUEL TANK 油箱




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	43110-CEW-00	FUEL TANK	汽油箱	1	
2	43151-RAM-00	GROMMET F	油箱套環 前	2	
3	43154-RAM-00	GUARD	保護板	1	
4	43500-RAM-01	FUEL COCK ASSY	油杯	1	
5	62770-CEW-01	SENDER UNIT ASSEMBLY	汽油油面感應器	1	
6	90210-12010	CLIP	管夾	2	
7	90310-50101	HOSE, FUEL 5*10*160	汽油管	1	
8	93510-061015-B	COLLAR F	油箱隔管 前	2	
9	93510-061021-B	COLLAR R	油箱隔管 後	2	
10	93580-102416	GROMMET R	油箱套環 後	2	
11	96310-05014-B	SCREW, PAN HEAD	十字孔頭螺絲	4	
12	96318-06012-G	SCREW, PAN HEAD	十字孔頭螺絲	2	
13	96414-06025-B	BOLT, FLANGE	凸緣螺栓	2	
14	96414-06032-B	BOLT, FLANGE	凸緣螺栓	2	
15	97201-051410-B	WASHER, PLATE	平面墊圈	4	
16	97201-062220-B	WASHER, PLATE	平面墊圈	4	
17	97210-061315	WASHER, PLATE	石棉墊圈	2	

WATER-COOLING SYSTEM 水冷卻系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	43400-CJW-00	RADIATOR ASSY	水箱總成	1	
2	43410-CJW-00	RADIATOR	水箱	1	
3	43411-JOW-00	BRACKET, RADIATOR	水箱上支架	1	
4	43416-JOW-00	BRACKET, RADIATOR	水箱下支架	1	
5	43420-CJW-00	HOSE, RADIATOR IN	水箱進水管	1	
6	43423-CJW-00	HOSE, RADIATOR CAP	加水口水管	1	
7	43424-JOW-00	HOSE	加水口連接管	1	
8	43425-CJW-00	HOSE, WATER PUMP IN	水泵進水管	1	
9	43427-JOW-01	JOINT	循環管接頭	1	
10	43428-CJW-00	HOSE, WATER CIRCULATE	冷水循環管	1	
11	43429-CJW-00	HOSE, RADIATOR	水箱通氣管	1	
12	43430-JOW-00	RADIATOR CAP	水箱蓋	1	
13	43435-JOW-00	HULL, RADIATOR CAP	水箱蓋體	1	
14	43440-CJW-00	RADIATOR DEFEND	水箱護罩	1	
15	43450-CJW-00	FAN MOTOR ASSY	風扇馬達總成	1	
16	43451-JOW-00	FAN MOTOR COMP	風扇馬達組	1	
17	43456-CJW-00	BRACKET, FAN	風扇支架	1	
18	43460-JOW-00	WATER TANK	副水箱	1	
19	43463-JOW-00	HOSE 1, WATER TANK	副水箱溢流管	1	
20	43466-JOW-00	CAP, WATER TANK	副水箱蓋	1	
21	43468-JOW-00	HOSE 2, WATER TANK	副水箱通氣管	1	
22	62750-CJW-00	FAN MOTOR SWITCH	風扇開關	1	

WATER-COOLING SYSTEM 水冷卻系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
23	90220-06077-D	CLAMP 6*7.7	1	H77
24	90220-08085-D	CLAMP 8*8.5	4	H85
25	90220-08110-D	CLAMP 8*11	3	H110
26	90220-08120-D	CLAMP 8*12	1	H120
27	90220-12198-B	CLAMP 12*19.8	2	
28	90220-12230-D	CLAMP 12*23	4	B-00067-07
29	93530-060911-K	COLLAR	2	
30	93580-092212	GROMMET	2	
31	93580-102212	GROMMET	2	
32	96218-06012-C	BOLT, HEXAGON WITH WASHER	4	
33	96218-06016-B	BOLT, HEXAGON WITH WASHER	2	
34	96218-06020-C	BOLT, HEXAGON WITH WASHER	3	
35	96310-04010-B	SCREW, PAN HEAD	3	
36	96414-06012-B	BOLT, FLANGE	1	
37	96414-06022-B	BOLT, FLANGE	2	
38	96616-05012-K	BOLT, HEXAGON WITH WASHER	4	
39	97201-040908-B	WASHER, PLATE 4.2*8.8*0.8	3	

REAR BRAKE 後剎車系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	QTY 用量	NOTE 備註
1	45801-CFS-01	CALIPER ASSY	1	
2	45815-RAM-01	PAD, CALIPER	1	
3	45830-RAM-00	BRACKET, DISC	1	
4	45831-RAM-00	DISC, BRAKE	1	
	45831-RAM-03	DISC, BRAKE	1	
5	45870-CJW-00	MASTER CYLINDER SUB ASSY	1	
6	45871-RAM-00	RESERVOIR	1	
7	45874-CJW-00	HOSE 8*13*270	1	
8	45877-RAM-01	CYLINDER KIT, MASTER	1	
9	45878-NAF-00	DIAPHRAGM, RESERVOIR	1	
10	45879-NAF-00	CAP, RESERVOIR	1	
11	61320-CJW-00	HOSE, BRAKE	1	
12	90220-08125-D	CLAMP 8*12.5	2	B-00106-07
13	90240-14016-B	COTTER PIN	1	
14	94610-06016-B	PIN, CLEVIS	1	
15	94706-08017-B	BOLT, BUTTON	4	
16	94712-04040-K	SCREW, FLAT HEAD	2	
17	94716-10022-G	BOLT, UNION	1	
18	94716-10033-G	BOLT, UNION	1	
19	96414-06016-B	BOLT, FLANGE	1	
20	96414-06022-B	BOLT, FLANGE	2	
21	96414-08045-B	BOLT, FLANGE	2	
22	97230-101512	WASHER, COPPER 10.3*15*1.2	5	
23	97301-081520-B	WASHER, SPRING	2	

STEERING KNUCKLE 轉向關節座




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	45811-CGV-00	CALIPER ASSY, L FRONT	左前卡鉗總成	1	
2	45815-RAM-01	PAD, CALIPER	剎車片組	2	
3	45821-CGV-00	CALIPER ASSY, R FRONT	右前卡鉗總成	1	
4	45831-RAM-01	DISK, BRAKE	剎車圓盤	2	
5	45860-CGV-00	KNUCKLE COMP, STEERING L	左前轉向關節座整體	1	
6	45865-CGV-00	KNUCKLE COMP, STEERING R	右前轉向關節座整體	1	
7	61811-CJW-01	HOSE, BRAKE	腳剎車油管	1	
8	61812-CGV-01L	HOSE, FRONT BRAKE L	左前剎車油管	1	
9	61812-CGV-01R	HOSE, FRONT BRAKE R	右前剎車油管	1	
10	61820-CJW-01	HOSE, HANDBRAKE	手剎車油管	1	
11	61860-JOW-01	BRAKE SHUNT ASSY	分流閥組	1	
12	90240-23020-B	COTTER PIN 2.3*20	開口銷	4	
13	94706-08017-B	BOLT, BUTTON	剎車盤固定螺栓	8	
14	94716-10022-G	BOLT, UNION	接合螺栓	5	
15	94716-10033-G	BOLT, UNION	接合螺栓	1	
16	95321-101710-C	NUT, CASTLE	有槽螺帽	4	
17	96414-06035-B	BOLT, FLANGE	凸緣螺栓	2	
18	96414-08020-B	BOLT, FLANGE	凸緣螺栓	4	
19	97201-101805-B	WASHER, PLATE	平面墊圈	4	
20	97230-101512	WASHER, COPPER	銅墊圈	13	

STEERING HANDLE CABLE 轉向把手、鋼索




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	46110-CGV-01	HANDLEBAR	把手整體	1	
2	46240-MAX-00	GRIP	握把	2	
	46240-RAM-00	GRIP	握把	2	
3	61340-CJW-01	CABLE, HANDBRAKE	手剎車鋼索	1	
4	61620-CJE-01	CABLE, THROTTLE	節流鋼索	1	
5	61720-CJW-00	CABLE, CHOKE	阻風導線	1	

FRONT FENDER 前土除




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	51151-CGW-00	PANEL, FRONT	前燈座	1	
2	51172-CGW-00	SIDE COVER L	左側蓋	1	
3	51173-CGW-00	SIDE COVER R	右側蓋	1	
4	51532-CGW-00	COVER, TOP	油箱上蓋	1	
5	51552-CGW-00	FENDER, FRONT L	左前土除	1	
6	51553-CGW-00	FENDER, FRONT R	右前土除	1	
7	51554-CGW-00	STAY, FENDER UPPER	前蓋固定座上	2	
8	51556-CGW-00J	STAY, FENDER LOWER	前蓋固定座下	1	
9	55213-CGW-00	PROTECTOR, HANDLEBAR	把手上蓋	1	
10	55315-CJW-00	STAY, HEAD LIGHT	前燈固定座	1	
11	55516-CGW-00	HOLDER, SPEEDOMETER	速度表固定座	1	
12	95101-05012	NUT, SPRING	U型板螺帽	21	
13	95101-061820-C	NUT, SPRING	U型板螺帽	2	
14	95401-061006-B	NUT, FLANGE	凸緣螺帽	2	
15	96108-51216-K	SCREW, TAPPING	自攻螺絲	1	
16	96112-51216-K	SCREW, TAPPING	自攻螺絲	16	
17	96318-06012-G	SCREW, PAN HEAD	十字孔頭螺絲	2	
18	96318-06015-G	SCREW, PAN HEAD	十字孔頭螺絲	2	
19	96414-06012-B	BOLT, FLANGE	凸緣螺栓	2	
20	96414-06016-B	BOLT, FLANGE	凸緣螺栓	2	
21	97321-061825-G	WASHER, FLANGE	凸緣墊圈	4	

REAR COVER 後蓋




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	13412-JOW-00	CAP, CLEANER CASE	空氣濾清器箱蓋	1	
2	13432-RAM-00	SEAL, ELEMENT	濾網固定板封圈	1	
3	13433-RAM-00	PLATE, ELEMENT SET	濾清網固定板	2	
4	13434-RAM-00	PLATE, JOINT	接頭壓板	1	
5	13435-RAM-00	STAY, JOINT	接頭固定片	1	
6	13437-CJW-00	DUCT	防塵管	1	
7	13451-RAM-00	ELEMENT, AIR CLEANER	空氣濾清網	1	
8	13452-RAM-00	SEAL, AIR CLEANER COVER	濾清箱封圈	1	
9	13453-CJW-01	TUBE, AIR CLEANER JOINT	濾清箱接頭	1	
10	51171-CGW-00	COVER, REAR	後蓋	1	
11	90260-80047	CLAMP, HOSE	連接管管夾	1	
12	93210-35900	O-RING	護油圈	1	
13	96110-43018-K	SCREW, TAPPING	自攻螺絲	8	
14	96310-05014-B	SCREW, PAN HEAD	十字孔頭螺絲	6	
15	96313-06020-K	SCREW, PAN HEAD WITH WASHER	十字孔頭螺絲附墊圈	4	
16	96318-06015-G	SCREW, PAN HEAD	十字孔頭螺絲	6	
17	96414-06012-B	BOLT, FLANGE	凸緣螺栓	1	
18	97321-061825-G	WASHER, FLANGE	凸緣墊圈	6	

SEAT 座墊




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	52710-RAM-00	CATCH COMP, SEAT	1	
2	52730-CDW-00	SEAT ASSY	1	
	52730-CDW-01	SEAT ASSY	1	▷ red low black
	52730-CDW-03	SEAT ASSY	1	▷ black low red
3	95401-061006-C	NUT, FLANGE	2	

STICK SHIFT 排檔裝置




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	53203-CJW-00	GEAR SHIFT LEVER LOWER	變速桿下	1	
2	53203-CJW-00A	GEAR SHIFT LEVER LOWER	變速桿下總成	1	
3	53207-JOW-00	JOINT L, GEAR SHIFT LEVER	變速桿接頭左	1	
4	53208-JOW-00	JOINT R, GEAR SHIFT LEVER	變速桿接頭右	1	
5	53209-JOW-00	NUT	變速桿螺帽	1	
6	53213-CJW-00	GEAR SHIFT LEVER UPPER	變速桿上	1	
7	53214-GKO-00	HEAD SHIFT	排檔頭	1	
8	53215-CJW-00	ARM SHIFT	排檔臂	1	
9	53217-CJW-00	GEAR SHIFT LEVER	變速桿搖臂	1	
10	53219-CEW-00	SPRING	排檔桿回位彈簧	1	
11	90230-12008	COTTER PIN	開尾銷	2	
12	95201-081207-B	NUT, HEXAGON	六角螺帽	1	
13	95201-101708-B	NUT, HEXAGON	六角螺帽	1	
14	95311-081308-B	NUT, NYLON	尼龍螺帽	2	
15	96218-06012-B	BOLT, HEXAGON WITH WASHER	六角螺栓附墊圈	2	
16	97201-061415-B	WASHER, PLATE	平面墊圈	2	
17	97221-071405	WASHER, PLASTIC	塑膠墊圈	4	

STAND FOOTREST 腳踏桿




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	QTY 用量	NOTE 備註
1	51177-CGW-00	STAY COVER L	1	後蓋前固定座左
2	51178-CGW-00	STAY COVER R	1	後蓋前固定座右
3	53231-CJW-00	FOOTREST L	1	左腳踏桿
4	53233-CEW-00	MUDGUARD STAY	1	左擋泥板架
5	53234-RAM-00	MUDGUARD L	1	左擋泥板
6	53241-CBS-00	FOOTREST R	1	右腳踏桿
7	53243-CEW-00	MUDGUARD STAY	1	右擋泥板架
8	53244-RAM-00	MUDGUARD R	1	右擋泥板
9	53261-CEW-00	PEDAL, BRAKE	1	後剎車踏板
10	95401-061006-B	NUT, FLANGE	2	凸緣螺帽
11	96214-06020-B	BOLT, HEXAGON WITH WASHER	4	六角螺栓附墊圈
12	96318-06012-G	SCREW, PAN HEAD	4	十字孔頭螺絲
13	96318-06015-G	SCREW, PAN HEAD	6	十字孔頭螺絲
14	96318-06020-G	SCREW, PAN HEAD	2	十字孔頭螺絲
15	96414-06012-B	BOLT, FLANGE	2	凸緣螺栓
16	96414-10025-B	BOLT, FLANGE	4	凸緣螺栓
17	97011-12010-B	CIRCLIP	1	E形扣環
18	97201-102220-B	WASHER, PLANE	2	平面墊圈
19	97201-152620-B	WASHER, PLANE 15.2*25.6*2.0	1	平面墊圈
20	97301-061215-B	WASHER, SPRING	2	彈簧墊圈
21	97321-061825-G	WASHER, FLANGE	8	凸緣墊圈
22	97506-16051-B	SPRING, TENSION	1	後剎車拉伸彈簧

HEADLIGHT 前燈




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	55300-CEW-00	HEAD LIGHT ASSY	前燈總成	1	
2	55314-CEW-00	BULB, HEAD LIGHT H4 12V35/35W	前燈燈泡	1	
3	55316-NGF-00	BULB, POSITION LAMP 12V 5W	位置燈燈泡	1	
4	55320-CEW-00	LENS ASSY	前燈單元總成	1	
5	55340-CEW-00	SOCKET CORD ASSY	燈座總成	1	
6	96112-51216-K	SCREW, TAPPING	自攻螺絲	4	

FLASHER 方向燈




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	55311-JOW-00	BULB FLASHER RY10W 12V 10W	方向燈泡	2	
2	55336-CGW-00	FLASHER STEADY, L FRONT	左前方向燈固定座	1	
3	55346-CGW-00	FLASHER STEADY, R FRONT	右前方向燈固定座	1	
4	55350-CGW-00	WINKER ASSY, L FRONT	前方向燈組左	1	
5	55360-CGW-00	WINKER ASSY, R FRONT	前方向燈組右	1	
6	55722-NCF-01	REFLECTOR	反射片	2	
7	55736-CGW-00	LOCK, WINKER	後方向燈固定座	2	
8	55750-CGW-00J	WINKER ASSY, L REAR	後方向燈組左	1	
9	55760-CGW-00J	WINKER ASSY, R REAR	後方向燈組右	1	
10	95101-05012	NUT, SPRING	U型板螺帽	8	
11	95401-050805-B	NUT, FLANGE	凸緣螺帽	2	
12	96108-51216-K	SCREW, TAPPING	自攻螺絲	4	
13	96112-51616-K	SCREW, TAPPING	自攻螺絲	4	
14	96612-05012-B	BOLT, HEXAGON WITH WASHER	六角十字穴螺栓附墊圈	2	
15	97201-051610-B	WASHER, PLANE	平面墊圈	2	
16	97301-061215-B	WASHER, SPRING	彈簧墊圈	2	

SPEEDOMETER 速度錶




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	55510-CJW-01	SPEEDOMETER ASSY	速度表總成	1	
2	61520-CJW-00	CABLE, SPEEDOMETER ASSY	速度表鋼索總成	1	
3	96112-51616-K	SCREW, TAPPING	自攻螺絲	3	

TAIL LIGHT 後燈




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	55700-CGV-00J	TAIL LIGHT ASSY	後燈總成	1	
2	55726-CBW-00	HOLDER, TAIL LIGHT	後燈固定座	1	
3	93510-061010	COLLAR	牌照板軸環	2	
4	93580-102212	GROMMET	牌照板套環	2	
5	95401-061006-B	NUT, FLANGE	凸緣螺帽	2	
6	96414-06012-B	BOLT, FLANGE	凸緣螺栓	2	
7	97201-061820-B	WASHER, PLATE	平面墊圈	2	

WARNING 警告標示




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	56576-RAM-00	LABEL WARNING 3 (TIRE)	胎壓規範	1	
2	56578-RAM-00	LABEL WARNING 2 (AGE)	年齡規範	1	
3	56781-RAM-01	LABEL WARNING 1 (OPERATION)	騎乘規範	1	

WIRE HARNESS 主電路配線




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	QTY 用量	NOTE 備註
1	43102-JPE-00	CAP ASSY	1	汽油箱蓋總成
2	56120-RAM-00	SCREW DRIVER	1	螺栓起子
3	56140-RAM-00	TOOL PLUG	1	火星塞工具
4	56190-RAM-00	GAUGE, AIR	1	胎壓計
5	61120-CJW-00	WIRE, HARNESS	1	主配線總成
6	61151-CHP-00	FUSE (15A250V)	1	保險絲
7	62100-CBT-00	BATTERY ASSY (YTX9A-BS)	1	蓄電池總成
	62100-CBT-01	BATTERY ASSY (GTX9A-BS)	1	蓄電池總成
8	62110-CBT-00	CABLE, BATTERY	1	蓄電池導線
9	62120-RAM-00	CABLE, EARTH	1	蓄電池接地線
10	62310-JOW-00	IGNITION COIL ASSY	1	點火線圈總成
11	62350-NAF-01	FLASHER RELAY ASSEMBLY	1	方向警報斷續器總成
12	62360-JOW-00	RECTIFIER & REGULATOR COMP	1	整流穩壓器
13	62370-NAF-00	HORN	1	喇叭
14	62500-CEW-01	KEY SET	1	鎖組
15	62501-JOW-00	MAIN SWITCH ASSY	1	主開關總成
16	62503-RAM-00	LOCK COMP, STEERING HANDLE	1	轉向舵鎖
17	62540-JOW-00	C.D.I UNIT ASSY	1	C.D.I組件總成
18	62550-JOW-00	STARTER RELAY SWITCH COMP	1	起動開關組
19	62980-CHP-00	SWITCH ASSY, REAR STOP	1	剎車燈後置開關
20	96414-06012-B	BOLT, FLANGE	2	凸緣螺栓
21	96414-06016-B	BOLT, FLANGE	2	凸緣螺栓

WIRE HARNESS 主電路配線




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
22	96414-06020-B	BOLT, FLANGE	2	凸緣螺栓
23	96613-05012-B	BOLT, HEXAGON WITH WASHER	2	六角十字穴螺栓附墊圈
24	97506-12140-B	SPRING, STOP SWITCH	1	剎車開關拉伸彈簧

HANDLE SWITCH, LEVER 把手開關、拉桿




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	45870-JOW-00	MASTER CYLINDER SUB ASSY	主缸總成	1	
2	45890-SK9-00	FRONT STOP SWITCH	前剎車燈開關	1	
3	56270-ROA-00	MIRROR ASSY, HANDLE	後照鏡組	1	
4	62910-SK9-02	LEVER ASSY, HANDLE	左拉桿組	1	
5	62912-SK9-02	LEVER, L	左拉桿	1	
6	62916-RAM-00	BOLT, WIRE ADJUSTING	離合器線調整螺栓	1	
7	62917-RAM-00	NUT, WIRE ADJUSTING	離合器線調整螺帽	1	
8	62920-JOW-00	THROTTLE ASSY	節流座總成	1	
9	62930-RAM-02	HANDLE SWITCH ASSY L	左把手開關總成	1	
10	62971-RAM-00	PIN, LOCK	拉桿鎖位銷	1	
11	62973-RAM-00	LOCK, LEVER	拉桿鎖位板	1	
12	62976-RAM-00	COVER	拉桿鎖位蓋	1	
13	62980-JOW-00	FRONT STOP SWITCH	前剎車燈開關	1	
14	94710-06031-G	BOLT, LEVER	拉桿螺栓	1	
15	95311-061006-K	NUT, NYLON	尼龍螺帽	1	
16	96310-03008-B	SCREW, PAN HEAD	十字孔頭螺絲	1	
17	96310-05030-G	SCREW, PAN HEAD	十字孔頭螺絲	1	
18	96310-05040-G	SCREW, PAN HEAD	十字孔頭螺絲	1	
19	96310-06010-G	SCREW, PAN HEAD	十字孔頭螺絲	1	
20	96510-06022-G	BOLT, SOCKET	六角承窩螺栓	1	
21	97201-061210-C	WASHER, PLATE 6.2*11.5*1.0	平面墊圈	1	
22	97201-061310-B	WASHER, PLATE 6.5*13*1.0	平面墊圈	1	
23	97501-08025-B	SPRING, COMPRESSION	拉桿鎖壓縮彈簧	1	

STAND FOOTREST 腳踏桿(for alloy pedal)




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	51177-CGW-00	STAY COVER L	後蓋前固定座左	1	
2	51178-CGW-00	STAY COVER R	後蓋前固定座右	1	
3	53231-CJW-00	FOOTREST L	左腳踏桿	1	
4	53241-CBS-00	FOOTREST R	右腳踏桿	1	
5	53261-CEW-00	PEDAL, BRAKE	後剎車踏板	1	
6	96318-06015-G	SCREW, PAN HEAD	十字孔頭螺絲	2	
7	96414-06012-B	BOLT, FLANGE	凸緣螺栓	2	
8	96414-10025-B	BOLT, FLANGE	凸緣螺栓	4	
9	97011-12010-B	CIRCLIP	E形扣環	1	
10	97201-102220-B	WASHER, PLANE	平面墊圈	2	
11	97201-152620-B	WASHER, PLANE 15.2*25.6*2.0	平面墊圈	1	
12	97321-061825-G	WASHER, FLANGE	凸緣墊圈	2	
13	97506-16051-B	SPRING, TENSION	後剎車拉伸彈簧	1	

PEDAL BUMPER 踏板保護架(Accessory)



NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		QTY 用量	NOTE 備註
1	53230-CEW-00	PEDAL BUMPER ASSY	踏板保護架總成	1	
2	53237-CEW-00	PEDAL BUMPER LEFT	左踏板保護架	1	
3	53238-CEW-00	PEDAL BUMPER SUPPORT	踏板保護架支持座	1	
4	53239-CEW-00L	PEDAL BUMPER BIND BELT L	踏板保護架束帶左	1	
5	53239-CEW-00R	PEDAL BUMPER BIND BELT R	踏板保護架束帶右	1	
6	53247-CEW-00	PEDAL BUMPER RIGHT	右踏板保護架	1	
7	94718-073033-B	BOLT	U形螺栓	2	
8	95401-081208-B	NUT, FLANGE	凸緣螺帽	4	
9	95501-071017-B	NUT, CUP	杯形螺帽	4	
10	96414-08020-B	BOLT, FLANGE	凸緣螺栓	4	
11	97201-082215-B	WASHER, PLATE	平面墊圈	4	
12	97301-081520-B	WASHER, SPRING	彈簧墊圈	4	

CROSS BAR KIT 把手橫桿組(Accessory)



NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	46115-CGV-00	CROSS BAR	把手橫桿	1	
2	46115-CGV-00A	CROSS BAR KIT	把手橫桿組	1	
3	46116-CGV-00	HOLDER, CROSS BAR	橫桿固定座	2	
4	96510-06020-G	BOLT, SOCKET	六角承窩螺栓	2	